
Hydro-Chi[™]

Water Electrolysis Machine



Tools and Supplies Needed ... but Not included

Description

- Teflon tape
- Crescent wrench
- Wire Cutters
- Drill
- Drill bits sizes 5/64 and 21/64
- Opened end wrench size 15mm
- Basin wrench
- Flathead screwdriver
- Flash light (to inspect for water leaks)
- Paper towels (to inspect for water leaks)

Qty	Descripion	Part	Image
1	Water Electrolysis Machine	Hydro-Chi	
1	Chi faucet fixture	A	
1	Acid spout	В	
1	Metal ring 45mm	С	
1	Hard plastic ring	D	0
1	Rubber gasket 42 mm	E	0
1	Small rubber gasket 29 mm	F	0
2	Hose clamp	Н	
1	Mounting template		0 0

Hydro-Chi Users Manual

Qty	Descripion	Part	Image
5	Mounting screws 30mm (Phillipshead)	J	
1	Ultra filter	K	
1	Instruction manual	L	Herico Chi Ten Francisco Nation Interesting Maria Interesting Maria Interesting Maria Interesting Maria
1	3-stage filters set	М	Hydro Chi" May Film
1	Filter wrench	N	4
2	White PE hose- 59 inches each	0	
1	Ball valve	P	
1	Tee joint	Q	
1	Tee joint gasket	R	0
1	Quick connect (spare)	S	

Contents

1.	Product Introduction	4
2.	Hydro-Chi™ Flow Chart	4
3.	Operation Requirements	5
4.	Visual Guide for Installation	6
5.	Installation Instructions	7
6.	Buttons Identified	10
7.	Display Screen	11
8.	How to Operate Machine	11
9.	Modes	12
10.	Mineral Port	12
11.	Adjusting Water Flow	13
12.	Optimizing the pH Settings	13
13.	Water Filters	14
14.	Warnings	15
15.	Warranty	16
16.	Troubleshooting	16

Thank you for purchasing the Hydro-Chi™ water electrolysis machine.

Please thoroughly read and follow the entire usage manual before operating your Hydro-Chi™.

> Refer back to this manual when questions arise. Call 229-365-7222 for customer support.


1. Product Introduction

The Hydro-Chi™ was designed with the capability to reach a pH maximum of 9.5 and a minimum of 6.0. Individual results will vary based upon the quality and characteristics of the well or city water being used. This machine is intended to be used with clean well or city water only.

Any time there is a major water (or food) change in ones diet, diarrhea or constipation is a possible side effect until the body adjusts to the new diet change. Therefore, it is recommended that one slowly introduce the water from the Hydro-Chi $^{\text{m}}$ into the diet for minimal body upset.

The more bubbles and cloudy the water coming from the alkaline faucet side, indicates the more hydrogen in the water. Since pH means, "potential Hydrogen," this means that the higher the "potential Hydrogen" selected on the Hydro-Chi™, the more bubbles and or cloudy the water should be.


2. Hydro-Chi[™] Flow Chart



Operation Requirements 3.

Voltage Rating	120V±10%/60Hz	
Maximum Power	≤150W	
Cleansing water flow	1.5 L/min	
Rated total net water flow	12000L	
Water pressure	Minimum 14psi - 58psi Maximum	
Water temperature	36°F~103°F	
pH value incoming water	6.8~7.2	
Electrical grade	I class	
Inlet water quality	Tap water	
Processed water quality	Agree with the regulations of life drinking water quality processor and functional assessments of health and safety norms, the general quality of the processor(2001)	
Waterproof class	IPx1	
External dimension	79.5X46X134(approx. inches)	
Net weight	8.8 lbs	

Hydro-Chi Users Manual



- 1. Ball valve connects to tee valve, parts P & Q
- 2. Incoming water source
- 3. Quick-connection
- 4. White PE hose, part O
- 5. White PE hose, part O
- 6. Compression nut
- 7. Gray hose for incoming water supply to Hydro-ChiTM
- 8. Quick-connection
- 9. Rigid ring, rubber gasket, parts D & F; and locking nut
- 10. Chi-faucet
- 11. Hose clamp (part H) one on each of the gray and beige hoses
- 12. Acid faucet
- 13. Beige acid faucet hose
- 14. Gooseneck faucet discharges hydrogen-rich water for drinking

5. **Installation Instructions**

Connecting Water Supply to the 3-Stage Water Filters

- 1. Inventory the contents of your boxes.
- **Turn off the water** to the cold water supply line that feeds water to 2. the (kitchen) sink.
- Make sure the gasket (part R) is inside the female side of the tee 3. joint (part Q).
- Connect the tee joint (part Q) to the cold water supply line. 4.
- Apply Teflon tape to the male end of the ball valve (part P). 5.
- Attach the tee joint to ball valve (part Q to part P). 6.
- 7. Unscrew the nut from the ball valve (part P).
- Take one (1) of the white PE hoses (part O) and slide the nut over the hose with the female threads facing the ball valve.
- Take the hose (with the nut) and push it firmly onto the ball valve 9. and then securely screw the nut to the ball valve.
- 10. Find a sturdy wall under the sink to mount the water filters ... must be no more than 55 inches from the water supply line.
- Mark the holes from the mounting bracket (part M) onto the wall. 11. Using a 5/64 drill bit, drill two pilot holes into the wood.
- Screw in 2 mounting screws (parts J) using a no. 2 Phillips. Leave 12. enough screw protruding from the wall to securely hang the mounted filters.
- 13. Hang the mounted filters onto the 2 mounting screws.
- Connect the loose end of the white PE hose which is connected to 14. the water supply line into the connection on the 3-stage water filters at the "IN" side. You will firmly push the hose into the Quick-Connection then pull the hose backward; making sure the connection is secure. NOTE: The


end of the white hose must have a straight edge and not be crimped. **Installing Chi-faucet and Connecting to 3-stage Water Filters**

- 15. Decide where the Chi-faucet will be installed at the sink. This water must have a drain to flow into (usually the sink). It can be installed on the sink in a pre-existing accessory hole or a new hole can be added. A 21/64 inch hole is required. Drill this hole as required.
- 16. Remove two (2) nuts from the end of the incoming water pipe on the Chi-faucet (from part A): the first is a compression nut, the second is a locking nut, notice the size differences.
- 17. Take the metal Ring (part C) and insert it onto the incoming water pipe of the Chi-faucet—the flat part of the ring facing upward.
- 18. Insert the large, thin gasket (Part E) behind the metal ring.
- 19. Insert the Chi-faucet (part A) into the hole on the sink (the incoming water pipe on the Chi-faucet is the part which goes into the hole).
- 20. Working from under the sink, first insert the rigid plastic ring (part D) onto the incoming water pipe on the Chi-faucet—fitting it snuggly; Secondly, insert the small rubber gasket (part F) directly behind the rigid plastic ring, which will hold the plastic ring in place.
- 21. Take the locking nut (the 2nd of the 2 nuts you removed at # 16) and screw it securely behind the small rubber gasket you last installed.
- 22. Take the other white PE hose (part P) and slide the compression nut over the hose (the 1st of the 2 nuts you removed at # 16).
- 23. Push the white hose securely over the barb on the end of the incoming water pipe of the Chi-faucet.
- 24. Screw the compression nut securely onto the same incoming water pipe on the Chi-faucet using a 15mm open-end wrench. Note: some installations will require a basin wrench instead of the 15mm open-end wrench.
- 25. Connect the other end of the white PE hose (one end of which is connected the incoming water pipe on the Chi-faucet) and connect it to the "OUT" end of the 3-stage water filters: firmly push the hose into the Quick-Connection then pull the hose backward; making sure the connection is secure. NOTE: The end of the white hose must have a straight edge and not be crimped.

Attach Hydro-ChiTM to Water Supply & Chi-faucet

- Remove the back cover on the Hydro-Chi. Remove the plugs from 26. the top and bottom of the filter housing and on the Ultra filter (part K). Follow the arrow directions on the Ultra filter (part K) to assure correct insertion. Press down on the filter as you insert the filter into the machine then lock it into place. Replace the back cover.
- 27. Slide one (1) hose clamp (part H) to each of the hoses on the Hydro-Chi: the gray hose and the beige hose. **Note:** hoses may be cut to desired length before proceeding further.
- Attach the gray hose to the bottom incoming water barb on the 28. Chi-faucet; tighten hose clamp (part H) with flathead screw driver.
- 29. Attach the beige hose to the top outgoing acid water barb on the Chi-faucet; tighten hose clamp (part H) with flathead screw driver.
- 30. Push the acid spout (part B) into top of Chi-Faucet.
- Remove the plug from the end of the gooseneck faucet. 31.
- **DO NOT PLUG** the Hydro-ChiTM into electric outlet yet. 32
- Slowly turn on the water supply under the sink. Open the Chi-33. faucet by turning the handle counterclockwise.
- Allow water to flow freely through Hydro-Chi for 20 minutes. This will flush away any potential activated carbon particles.
- Inspect all water connections; use a flashlight to look for any signs 35. of leaks. Use a paper towel as a wick to inspect places you are unable to see with the flashlight.
- 36. If leaks are detected, turn off water and tighten leaky joints.
- Close the Chi-faucet by turning the handle clockwise. Repeat steps 37. 33-37 until there are no leaks.
- 38. Plug the Hydro-Chi into electric outlet.
- 39. Open the Chi-faucet by turning the handle counterclockwise. The display should turn on.
- Congratulations you have completed the Hydro-ChiTM installation!

6. Buttons Identified



• There is a small green light on the left side of each button. The light flashes green as a warning that the water selection is not yet ready to drink. A solid green light indicates that the selected water is ready to drink.

7. Display Screen

- **PH:** Potential Hydrogen content for selected water output
- **TDS:** Total Dissolved Solids in selected water output
- **ORP:** Oxidation Reduction Potential in selected water output
- **Remaining Filter Life:** Time left for Ultra Chi Filter
- Flow Rate: The flow rate of incoming water to the Hydro-ChiTM



8. How to Operate Machine

Turn on the water using the knob at the Chi faucet. The display screen will light up red and an audible beeping will sound for 3-6 seconds. Next select a water button of either:

- Hydrogen Level 3
- Hydrogen Level 2
- Hydrogen Level 1
- Neutral Water
- Acidic water

The display screen will light up in a different color with each selection and a beep sound is audible with each water selection.

There is a small green light on the left side of each water button. The light flashes green as a warning that the water selection is not yet ready to drink. A solid green light indicates that the selected water is ready to drink.

The water dispensed from the Gooseneck is the water which should be drank. The water dispensed from the Acid Faucet should NOT be drank. It may be used for cleaning.

9. Modes

Electrode Cleaning: Each time the Hydro-ChiTM is turned on by turning the Chi faucet counterclockwise, 12 seconds are devoted to electrode cleaning-- during which time the display will light up in red and a beeping sound is audible. Periodically, the machine will perform an automatic electrode cleaning at which time the display will light up in red and the warning beep will sound continuously. Wait until the display is no longer red and the warning beeping has subsided before making a water selection and drinking the dispensed water. After cleaning, the machine automatically selects *Neutral Water*.

Energy Saving Mode: The color on the display screen will disappear after 15 seconds to save power and energy.

Sleeping Mode: After 3 minutes of no use, the display screen will go blank when it goes into sleeping mode.

10. Mineral Port

Located on top of the Hydro-ChiTM is the mineral port. Only *Chi-Mineral Balls*--available from BioAnue Health Products-- should be added to this port. Chi-Minerals help increase mineral content in the water for optimal water electrolysis.

To add Chi-Minerals:

- 1. Unscrew the port cap and add the mineral into the port.
- Screw the lid back in place before using.
- 3. Run the Hydro-Chi for 10 minutes to activate the Chi-Minerals.

To change out your Chi-Minerals for new or different type:

- 1. Unscrew the port cap and gently turn the $Hydro-Chi^{TM}$ upside down so the old minerals can fall out of the port.
- 2. Turn the machine right side up and add the new Chi-Minerals.
- 3. Screw the port cap into place before running the machine.
- 4. Flush the machine 10 minutes every time new Chi-Minerals are added to activate the mineral balls.

11. Adjusting Water Flow

Warning beeps will sound and the display will light up red when the incoming water flow to the Hydro-Chi™ is too fast or too slow. Notice that the current flow rate can be observed on the display screen on the left side. A too slow flow is 0.8 liters per minute (L/M) or lower. A too fast water flow is 2.5l/m and higher. If the warning does not subside after 30 seconds, follow these instructions:

- Leave the faucet on and go under the sink to adjust the ball valve by turning the handle to open or close as needed.
- When the adjustment is correct, the warning beeping will stop. Now you can turn off the water faucet to the Hydro-Chi.
- If this adjustment does not fix a too slow water flow warning, this can mean that the water filters under the sink require replacement.
- The recommended water flow is between 1.0-2.0L/M. The current flow rate can be observed on the display screen.

12. Optimizing the pH Settings

An internal pH of 0 is the lowest pH setting and will result in the lowest possible pH output for that type of selected water. An internal pH of 9 is the highest pH setting and will result in the highest possible pH output for that type of selected water. Water must be turned off to the Hydro-ChiTM to change the pH number settings.

- 1. Press Reset Filter and Neutral Water simultaneously for 3 seconds, a blank screen appears (no words or numbers) and the yellow Indicator of Change Filter light turns on.
- Select either <u>Hydrogen 3</u>, <u>Hydrogen 2</u>, <u>Hydrogen 1</u>,or <u>Acidic Water</u> 2. by pressing the corresponding button to change the pH value of that selected water (Neutral Water cannot be changed).
- Press Neutral Water to change the number from 0 to 9 (after 9 it 3. loops back to 0).
- Press the water selection again to save (Example, if you are adjusting Hydrogen 3, press Hydrogen 3 to save your changes, a long beep will sound).
- Press Reset Filter two times to exit (a beep will sound each time). 5.

How to obtain the highest level of alkalinity with the Hydro-Chi.

The Gooseneck faucet will dispense acidic water when on the Acidic Water setting. Thus, the water flowing out of the opposite faucet (the acidic faucet) will dispense strong alkaline water- this is the highest alkalinity obtainable with the Hydro-ChiTM.

Note: The water dispensed from the acidic faucet is 1/3 the volume compared to the water dispensed from the alkaline side through the Gooseneck.

13. Water Filters

Insert the Ultra water filter inside the Hydro-Chi[™] for first time.

Remove the back cover on the machine. Remove the plugs from the top and bottom of the filter housing. Follow the arrow directions on the new water filter to assure correct insertion. Press down on the filter as you insert the filter into the machine then lock it into place. Replace the back cover. Allow water to flow through the machine for 10 minutes before plugging into electric outlet. Do not drink any of the dispensed water.

Note: Upon initial installation and any time the Chi filter has been replaced inside the machine, allow water to flow through the Hydro-Chi for 10 minutes before drinking any of the dispensed water.

When to Replace Water Filters

The Ultra filter inside the Hydro-Chi[™] must be changed when the Remaining Filter Life reads 0.00, OR if the 3-stage filters get clogged before the Remaining Filter Life reads 0.00.

Insert the new filter: Follow the arrow directions on the new water filter to assure correct insertion. Press down on the filter as you insert the filter into the Hydro-ChiTM then lock it into place. Replace the back cover. Allow water to flow through the machine for 10 minutes before plugging back into electric outlet.

Reset the Remaining Filter Life: (Only to be reset when filter has been replaced.)

1. Press Reset Filter and Neutral Water simultaneously, a blank screen

appears (no words or numbers)

2. Press Neutral Water to set the new filter to 12000L (twelve thousand liters).

Changing the 3-Stage Filters

Not all three filters must be changed at the same time. You must determine which filters to change by examining the problem.

Change all 3 filters when:

- The water flow rate remains below .8l- this indicates that the filters are clogged with sediment and/or other contaminates.
- The water flow remains below .5l and the warning and beeping cannot be corrected by adjusting the ball valve.

Change the 2 Carbon Filters (filters 2 & 3) when: Chlorine can be smelled or tasted in the drinking water- this indicates that those two filters have reached the filtration capacity.

One Year has passed since last change.

Upon initial installation and after the 3-stage filters have been changed, allow water to flow through the Hydro-Chi[™] for 10 minutes before drinking any of the dispensed water.

14. Warnings

- 1. Place machine on a level surface with adequate ventilation away from high or freezing temperatures, direct sunlight, rain, and standing water or splashing water.
- 2. Surrounding temperature range should not be lower or higher than 36 F to 103 F.
- 3. Do not allow machine to freeze- this will damage machine.
- 4. Do not use water any warmer than 103 F as this can damage the machine.
- 5. Only clean well or city water should be used.
- 6. Do not carry the machine by the Gooseneck.
- 7. Keep the machine in an upright position.
- 8. Limit use to 15 minute intervals.
- 9. If water comes out warm, stop usage and allow machine to cool down.
- 10. Never add soap or any other unapproved substances to the machine.

- 11. Allow 10 minutes of water to run through machine if it is unused for 3 days or more.
- 12. When not in use, unplug the machine.
- 13. Professional repairmen or mechanically-competent individuals should install and change the filters to the machine.
- 14. Only factory approved representatives should repair the machine.

15. Warranty

This machine has a 5 year warranty. If the internal and expected functions should fail during the five year from date of purchase, please contact *BioAnue Health Products* for instructions to have it repaired or replaced. Ph: **229-365-7222** Please keep your receipt to verify purchase date.

The following will **VOID** the one year warranty:

- Lack of receipt
- Incorrect Usage
- Accidental Damage
- Usage of non-approved filters and parts
- Failure to replace filters as needed
- Power Surge damage
- Mother-Nature such as lightning, fire, earthquake, floods, tornadoes, etc.

16. Troubleshooting

Problem	em Possible Causes Solution	
Display failed to light or turned black suddenly	Might be in energy saving modeNo electrical power	Check for energy saving modeConnect to electrical power
Leaking	Loose fittingsO rings are worn	Tighten as neededApply petroleum jellyReplace the O ring and apply petroleum jelly

Problem	Possible Causes	Solution
No water comes out	 There is no water supply Water inlet valve is turned off Filter is too dirty, causing a clog 	 Check to confirm the inlet valve is turned on Change the water filter
Slow water flow	 Supply water is slow The water pressure is low The filter is too dirty or overused 	 Increase the water flow at ball valve Increase the main water pressure Replace the filters
Water leakage from bottom of machine	The Ultra filter is installed incorrectly (upside down)	Install the internal filter in correctly

BioAnue Health Products Inc.

P.O. Box 513 Abbeville, GA 31001 USA Phone number 229-365-7222 or support@bioanuehealth.com

www.bioanuehealth.com